



10' Trailer Quick Reference.

One Cord Operation.

1. Plug in Cord #1 into Electrical Port.
2. Unplug Converter Cord from Receptacle.
3. Plug Converter Cord into Service Area Receptacle.
4. Turn Breakers on AC/Service Area.

When towing the restroom trailer it is required that the waste and fresh water tank be pumped and drained to prevent structural damage or unsafe driving conditions. The stairs and hand rails need to be secured in place as well. When connecting the trailer to a tow vehicle, attach the safety chains and breakaway cable to the tow vehicle.

On Site:

1. Level Trailer
2. Deploy Sidewinder Jacks.
3. Deploy Folding Steps and Handles.
4. Connect Power Cord to Power Source. (See Electrical)
5. Connect 3/4" Garden Hose to Trailer Water Connection. (See Plumbing)
6. At Service Area, Turn on Main Breaker. (See Electrical)
7. At Service Area, Turn on All AC breakers. (See Electrical)
8. At Service Area, Turn on Converter Breaker. (See Electrical)
9. At Service Area, Open Bottom City Water Valve. (See Plumbing)
10. At Service Area, Close Upper Water Tank Valve. (If Fresh Tank Only.) (Plumbing)
11. At Service Area, Turn on Master Pump Breaker. (See Electrical)
12. At Service Area, Turn on Water Pump Switch. (See Electrical)

After your event has ended the trailer is ready for tear down and transportation home.

Pull jacks up, lock folding steps and handles, shut off all electrical outlets, place all cords in storage compartment, disconnect plumbing from trailer and secure all electrical and plumbing storage compartments and close all vents.

Refer to the provided manual for operation, maintenance and troubleshooting.

CONTACTING CUSTOMER SERVICE:

CALL THE MAIN BUSINESS OFFICE AT 574-350-2150 FROM 8 AM - 4 PM EASTERN TIME ZONE. AFTER HOURS CALL 574-596-1626 OR 704-287-2065